

# TOYOTA

## ELECTRICAL WIRING DIAGRAM

TOYOTA **SUPRA**

1987 MODEL

# FOREWORD

This wiring diagram has been prepared to provide information on the electrical system of the 1987 TOYOTA SUPRA.

Applicable models: MA70 series

For other service specifications and repair procedures of the 1987 TOYOTA SUPRA than listed in this manual, refer to the following repair manuals;

| Manual Name                     | Pub No. |
|---------------------------------|---------|
| 1987 Toyota Supra Repair Manual | RM043U  |
| TCCS (7M-GE) Diagnosis Manual   | DM008U  |
| ECT (A340E) Diagnosis Manual    | DM006U  |

All information in the manual is based on the latest product information at the time of publication. However, specifications and procedures are subject to change without notice.

**TOYOTA MOTOR CORPORATION**



# 1987 TOYOTA SUPRA

## ELECTRICAL WIRING DIAGRAM

|                                     |   |                                              |    |
|-------------------------------------|---|----------------------------------------------|----|
| INTRODUCTION .....                  | A | TURN SIGNAL AND HAZARD WARNING LIGHTS .....  | 6  |
| HOW TO USE THIS MANUAL .....        | B | HEADLIGHTS .....                             | 7  |
| TROUBLESHOOTING .....               | C | FOG LIGHTS .....                             | 8  |
| GLOSSARY OF TERMS AND SYMBOLS ..... | D | INTERIOR LIGHTS .....                        | 9  |
| POWER SOURCE .....                  | 1 | BACK-UP LIGHTS .....                         | 10 |
| STARTING AND IGNITION SYSTEM .....  | 2 | STOP LIGHTS .....                            | 11 |
| EFI SYSTEM .....                    | 3 | TAILLIGHTS AND ILLUMINATION .....            | 12 |
| CHARGING SYSTEM .....               | 4 | REMOTE CONTROL MIRRORS .....                 | 13 |
| LIGHT AUTO TURN OFF SYSTEM .....    | 5 | REAR WINDOW DEFOGGER AND MIRROR HEATER ..... | 14 |
|                                     |   | FRONT WIPER AND WASHER .....                 | 15 |
|                                     |   | DOOR LOCKS .....                             | 16 |
|                                     |   | REAR WIPER AND WASHER .....                  | 17 |
|                                     |   | POWER WINDOWS .....                          | 18 |
|                                     |   | POWER SEAT .....                             | 19 |
|                                     |   | CRUISE CONTROL .....                         | 20 |
|                                     |   | ECT SYSTEM .....                             | 21 |
|                                     |   | A. B. S. ....                                | 22 |
|                                     |   | HEADLIGHT CLEANER .....                      | 23 |
|                                     |   | CIGARETTE LIGHTER AND CLOCK .....            | 24 |
|                                     |   | TEMS .....                                   | 25 |
|                                     |   | UNLOCK AND SEAT BELT WARNING .....           | 26 |
|                                     |   | SUPER MONITOR .....                          | 27 |
|                                     |   | HORNS .....                                  | 28 |
|                                     |   | THEFT DETERRENT SYSTEM .....                 | 29 |
|                                     |   | AUTO ANTENNA .....                           | 30 |
|                                     |   | RADIO AND TAPE PLAYER .....                  | 31 |
|                                     |   | COMBINATION METER .....                      | 32 |
|                                     |   | AUTOMATIC AIR CONDITIONER .....              | 33 |
|                                     |   | GROUND POINTS .....                          | 34 |
|                                     |   | RELAY LOCATIONS .....                        |    |
|                                     |   | ELECTRICAL WIRING ROUTING .....              |    |
|                                     |   | OVER ALL ELECTRICAL WIRING DIAGRAM .....     |    |

© 1986 TOYOTA MOTOR CORPORATION

All rights reserved. This book may not be reproduced or copied, in whole or in part, without the written permission of Toyota Motor Corporation.

A INTRODUCTION

This manual is composed of the following 5 elements.

| Power Source | System Circuit | Ground Points | Relay Location & Wiring Routing | Over all Wiring Diagram |
|--------------|----------------|---------------|---------------------------------|-------------------------|
|--------------|----------------|---------------|---------------------------------|-------------------------|


Circuit from battery to each fuse









Each circuit classified by system

Relation between ground points of each component


Relay & Connector location

Shows relation between each system




| Components                                                                                                                                                                 | Circuit                                                                                                       | Connector                                                                                                        | Location                                                                  |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------|
|                                                                                          | <br>③ HEADLIGHT LH         | <br>③<br>(Wire Harness Side)  | ③⑤ Headlight LH<br>Wiring routing components listed in alphabetical order |
| <br>Junction Block No. 2<br>Note: The number indicates the number of the junction block. | <br>④ ②C<br>P-W            | <br>②C<br>(Wire Harness Side) | ②C Engine Room Main Wire & Junction Block No. 2                           |
| <br>Wire to Wire Connector                                                               | <br>Male<br>Female<br>④ E1 | <br>Female      Male<br>E1    | E1 Engine Room Main Wire & Cowl Wire                                      |

## 14 REAR WINDOW DEFOGGER




Ⓐ Pin Number

Numbered in order  
from upper left to  
lower right



Female


Numbered in order  
from upper right to  
lower left



Male

④ Indicates circuit in Junction Block No. 3.

Example:



1C indicates that it is inside Junction Block No. 1.

## ⑤ Troubleshooting Hints & Components Operation

⑦ Wire Color

Wire colors are indicated by an alphabetical code.

B = Black    L = Light Blue    R = Red


BR = Brown    LG = Light Green    V = Violet

G = Green    O = Orange    W = White

GR = Gray    P = Pink    Y = Yellow

The first letter indicates the basic wire color and the second letter indicates the color of the stripe.

Example: R—G



## ABBREVIATIONS

The following abbreviations are used in this manual.

A/C = Air Conditioner

FL = Fusible Link

RH = Right-hand

A/T = Automatic Transmission

J/B = Junction Block

S/W = Switch

CB = Circuit Breaker

LH = Left-hand

VSV = Vacuum Switching Valve

ECT = Electronic Controlled Transmission

M/T = Manual Transmission

W/ = With

EFI = Electronic Fuel Injection

O/D = Overdrive

W/O = Without

## B HOW TO USE THIS MANUAL


To better understand how to use this manual, let's assume that the headlights will not light, and go through an actual troubleshooting procedure.

## CONFIRMATION OF TROUBLE

Turn on the headlight switch and check for yourself that the headlights do not come on.

## READ THE CIRCUIT DIAGRAM



1. Locate the headlight system number in the index and open the manual to the page indicated. (The system number is written in bold at the top corner of each page).
2. Read the circuit diagram to learn how it works.
3. Unfold the ELECTRICAL WIRING ROUTING page at the back of the manual.



## PINPOINT THE TROUBLE


If the circuit is in common with others (power circuit or ground point), problems will occur in some of the others also. Please refer to POWER SOURCE (System No. 1-2). Since the headlights are related to the HAZ-HORN, check this circuit.

Okay . . . . . Trouble lies within the headlight circuit.  
Bad . . . . . Check circuits in common.



1. Inspection of Headlight Circuit  
(Return to HEADLIGHT page.)
  - (a) Check Headlight Fuse
    - ① According to ②D of the circuit, the headlight fuse is in J/B No. 2.
    - ② The location of J/B No. 2 can be found by referring to the RELAY LOCATIONS page just before the ELECTRICAL WIRING ROUTING page.
    - ③ Check if either fuse is blown.
  - (b) Check if there is power to pin No. 5 of ②D .
    - ① Turn the light control switch to HEAD.
    - ② Using a voltmeter, check for voltage as shown below.

{ Negative (-) Probe . . . . . Good ground point or negative battery terminal.  
 { Positive (+) Probe . . . . . Pin No. 5 of (2D) .



Battery Voltage . . . . . Trouble is past pin No. 5 of 2D .  
 No Battery Voltage . . . . . Trouble is before pin No. 5 of 2D .

#### CAUTION:

Insert the tester probes from the wire harness side of the connector. Consequently, note that the pin numbers will be in reverse order of that shown in the illustration.

(c) Check if there is power to the headlights.

- ① From the circuit we can see that ② is the headlight connector and that there is power from pin No. 3 to 2 when the headlights are at high beam.
- ② Turn the light control switch to **HEAD**.
- ③ Place the dimmer switch at **HI**.
- ④ Using a voltmeter, check for voltage as shown below.

{ Negative (—) probe . . . Pin No. 2 of connector ② .  
 { Positive (+) probe . . . Pin No. 3 of connector ② .

Voltage . . . . . Trouble is in the headlight.  
 No Voltage . . . . . Probable defective ground past pin No.2 so make contact with negative lead to a good ground point or battery negative terminal and check for voltage.

Voltage . . . . . Trouble is past pin No. 2 of ② .  
 No Voltage . . . . . Trouble is before pin No. 3 of ② .


#### CAUTION:

Do not check for continuity while voltage is applied or it may result in damage to the tester.

(d) To check the low beam, place the dimmer switch at **LOW** and perform the check in the same sequence.

(e) Check ground point

- 1 The ground point is indicated by the ▽ J/B No. 1 SET BOLT in the circuit.
- 2 The location of the ground point on the vehicle can be found by referring to the same symbol ▽ in **ELECTRICAL WIRING ROUTING**.








## 1-1 POWER SOURCE (Power-Load Reference)

| J/B No.2 (Engine Compartment) |             |                                                                                                                                                                                                                                                  |
|-------------------------------|-------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 30A                           | RTR         | Retract Control Relay (Integration Relay No. 2)                                                                                                                                                                                                  |
| 7.5A                          | CHARGE      | Alternator                                                                                                                                                                                                                                       |
| 15A                           | HEAD LH     | Headlight (LH)                                                                                                                                                                                                                                   |
| 15A                           | HEAD RH     | Headlight (RH)                                                                                                                                                                                                                                   |
| 15A                           | HAZ HORN    | Turn Signal Flasher<br>Horns, Horn Relay<br>Theft Deterrent Horn                                                                                                                                                                                 |
| 15A                           | EFI         | Circuit Opening Relay, TCCS ECU, Check Connector, ISC Valve,<br>VSV (EGR, Fuel Pressure up and Intake Air Control), OX Sensor<br>ECT ECU<br>Clock<br>Super Monitor Computer<br>Theft Deterrent Computer<br>Auto Antenna<br>Radio and Tone Player |
| 15A                           | RADIO NO. 1 |                                                                                                                                                                                                                                                  |

## 1-2 POWER SOURCE



## 2. Inspection of Common Circuits

(a) Check battery and fusible link

(b) Check related systems

Check how the HEAD FUSE is related to the system. In system No. 1-1 (POWER SOURCE), you will find a chart listing the relationship between the fuses and components. Here we can see that the HEAD fuses are related only to their respective headlights.

(c) Check the circuit from the battery to the HEAD FUSE.

① In system No. 1-2 (POWER SOURCE), the power circuits for all fuses are listed. The circuit between the battery and HEAD fuse branches off with fuses HAZ-HORN 15A etc.

② Turn on the HAZARD switch

Okay . . . . No trouble in circuit up to HAZ-HORN junction.  
Bad . . . . . Trouble lies between fusible link and J/B No. 2.

(d) Check the HEADLIGHT RELAY  
(Return to HEADLIGHT page)

1 The circuit shows that the HEADLIGHT RELAY is in J/B No. 2.

2 Installation of the relay can be found by referring to the RELAY LOCATIONS. The HEADLIGHT RELAY is located in J/B No. 2 in the engine compartment as shown.


3 Check for power to the headlight relay coil.

① Turn the headlight switch to HEAD.


② Using a voltmeter, check for voltage as shown below.

{ Negative (–) Probe . . . . Pin No. 6 of (2B) .  
Positive (+) Probe . . . . . Pin No. 2 of (2A) .


Confirm that there is voltage




If no voltage, trouble lies in the headlight relay.



The ground points are listed in system No. 34 (GROUND POINTS). As shown, GROUND POINT  is used for other components besides the HEADLIGHT SYSTEM, and it also connected to GROUND POINT .



1 From the EWD SYSTEM INDEX (facing the first EWD), we can find the location of the headlight system within the ELECTRICAL WIRING DIAGRAM at the back of the book (Page 5 of 8, grid 7).



The relationship between system circuits is not shown so always confirm with the overall wiring diagram.

After repair, check that the circuit functions normally. Always follow the steps described above to narrow down the possible range of the trouble.


## VOLTAGE CHECK

- (a) Establish conditions in which voltage is present at the check point.

Example:



- Ⓐ— Ignition S/W on
- Ⓑ— Ignition S/W and S/W 1 on
- Ⓒ— Ignition S/W, S/W 1 and Relay on (S/W 2 off)

- (b) Using a voltmeter, connect the negative lead to a good ground point or negative battery terminal, and the positive lead to the connector or component terminal. This check can be done with a test light instead of a voltmeter.



## CONTINUITY AND RESISTANCE CHECK


- (a) Disconnect the battery terminal or wire so there is no voltage between the check points.
- (b) Contact the two leads of an ohmmeter to each of the check points.



If the circuit has diodes, reverse the two leads and check again.


When contacting the negative lead to the diode positive side and the positive lead to the negative side, there should be continuity.

When contacting the two leads in reverse, there should be no continuity.



- (c) Use a volt/ohmmeter with high impedance ( $10\text{ k}\Omega/\text{V}$  minimum) for troubleshooting of the electrical circuit.






## FINDING A SHORT CIRCUIT

- Remove the blown fuse and disconnect all loads of the fuse.
- Connect a test light in place of the fuse.
- Establish conditions in which the test light comes on.

Example:


- Ignition S/W on
  - Ignition S/W and S/W 1 on
  - Ignition S/W, S/W 1 and Relay on (Connect the Relay) and S/W 2 off (or Disconnect S/W 2)
- Disconnect and reconnect the connectors while watching the test light.  
The short lies between the connector where the test light stays lit and the connector where the light goes out.
  - Find the exact location of the short by lightly shaking the problem wire along the body.

# D GLOSSARY OF TERMS AND SYMBOLS



## BATTERY


Stores chemical energy and converts it into electrical energy. Provides DC current for the auto's various electrical circuits.




## HEADLIGHTS

### 1. SINGLE FILAMENT

Current flow causes a headlight filament to heat up and emit light. A headlight may have either a single (1) filament or a double (2) filament.



### 2. DOUBLE FILAMENT



## CAPACITOR (Condenser)

A small holding unit for temporary storage of electrical voltage. Capacitors with a ground connection are frequently called Condensers.



## CIGARETTE LIGHTER

An electric resistance heating element.




## HORN

An electric device which sounds a loud audible signal.



## CIRCUIT BREAKER

Basically a reusable fuse, a circuit breaker will heat and open if too much current flows through it. Some units automatically reset when cool, others must be manually reset.



## IGNITION COIL


Converts low-voltage DC current into high-voltage ignition current for firing the spark plugs.



## DIODE

A semiconductor which allows current flow in only one direction.

## DIODE, ZENER




A diode which allows current flow in one direction but blocks reverse flow only up to a specific voltage. Above that potential, it passes the excess voltage. This acts as a simple voltage regulator.



## LIGHT

Current flow through a filament causes the filament to heat up and emit light.



## DISTRIBUTOR, IIA

Channels high-voltage current from the ignition coil to the individual spark plugs.



## LED (LIGHT EMITTING DIODE)

Upon current flow, these diodes emit light without producing the heat of a comparable light. Used in instrument displays.



## FUSE

A thin metal strip which burns through when too much current flows through it, thereby stopping current flow and protecting a circuit from damage.



## METER, ANALOG

Current flow activates a magnetic coil which causes a needle to move, thereby providing a relative display against a background calibration.



## FUSIBLE LINK

A heavy-gauge wire placed in high amperage circuits which burns through on overloads, thereby protecting the circuit.



## METER, DIGITAL

Current flow activates one or many LED's, LCD's, or fluorescent displays, which provide a relative or digital display.





## GROUND

The point at which wiring attaches to the chassis, thereby providing a return path for an electrical circuit; without a ground, current cannot flow.




## MOTOR

A power unit which converts electrical energy into mechanical energy, especially rotary motion.

**RELAY****1. NORMALLY CLOSED****2. NORMALLY OPEN**


Basically, an electrically operated switch which may be normally closed (1) or open (2). Current flow through a small coil creates a magnetic field which either opens or closes an attached switch.

**RELAY, DOUBLE THROW**

A relay which passes current through one set of contacts or the other.

**RESISTOR**


An electrical component with a fixed resistance, placed in a circuit to reduce voltage to a specific value.

**RESISTOR, TAPPED**


A resistor which supplies two or more different non-adjustable resistance values.

**RESISTOR, VARIABLE or RHEOSTAT**


A controllable resistor with a variable rate of resistance. Also called a potentiometer or rheostat.

**SENSOR (Thermistor)**


A resistor which varies its resistance with temperature.

**SENSOR, ANALOG SPEED**


Uses magnetic impulses to open and close a switch to create a signal for activation of other components.

**SHORT PIN**



Used to provide an unbroken connection within a junction block.

**SOLENOID**


An electromagnetic coil which creates a magnetic field upon current flow, to move a plunger, etc.

**SPEAKER**


An electromechanical device which creates sound waves from current flow.

**SWITCH, MANUAL****1. NORMALLY OPEN****2. NORMALLY CLOSED**


Opens and closes circuits, thereby stopping (1) or allowing (2) current flow.

**SWITCH, DOUBLE THROW**


A switch which continuously passes current through one set of contacts or the other.

**SWITCH, IGNITION**


A key operated switch with several positions which allow various circuits. Particularly the primary ignition circuit, to become operational.

**SWITCH, WIPER PARK**

Automatically returns wipers to the stop position when the wiper switch is turned off.

**TRANSISTOR**

A solidstate device typically used as an electronic relay; stops or passes current depending on the applied voltage at "base".

**WIRES****1. NOT CONNECTED****2. SPLICED**

Wires are always drawn as straight lines on wiring diagrams. Crossed wires (1) without a black dot at the junction are not joined; crossed wires (2) with a black dot at the junction are spliced (joined) connections.



## J/B No.1 (Left Kick Panel)

| Power |            | Load                                                                                                                                                                                                                                                                                                                                                     | System No. |
|-------|------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------|
| 7.5A  | IGN        | TCCS ECU                                                                                                                                                                                                                                                                                                                                                 | 3          |
|       |            | Charge Warning Light                                                                                                                                                                                                                                                                                                                                     | 4          |
|       |            | Super Monitor Computer                                                                                                                                                                                                                                                                                                                                   | 27         |
| 20A   | WIPER      | Washer Motor, Wiper Motor, Wiper Relay                                                                                                                                                                                                                                                                                                                   | 15         |
|       |            | Rear Washer Motor, Rear Wiper Relay, Rear Wiper Motor                                                                                                                                                                                                                                                                                                    | 17         |
|       |            | Headlight Cleaner Relay                                                                                                                                                                                                                                                                                                                                  | 23         |
| 20A   | STOP       | Stop Lights, Hi Mount Stop Light, Light Failure Sensor                                                                                                                                                                                                                                                                                                   | 11         |
|       |            | Cruise Control Computer                                                                                                                                                                                                                                                                                                                                  | 20         |
|       |            | ECT ECU                                                                                                                                                                                                                                                                                                                                                  | 21         |
|       |            | A.B.S. Computer                                                                                                                                                                                                                                                                                                                                          | 22         |
| 7.5A  | TURN       | Turn Signal Flasher                                                                                                                                                                                                                                                                                                                                      | 6          |
| 7.5A  | GAUGE      | Check Engine Warning Light                                                                                                                                                                                                                                                                                                                               | 3          |
|       |            | Light Retainer Relay (Integration Relay No. 2)                                                                                                                                                                                                                                                                                                           | 5          |
|       |            | Back-up Lights                                                                                                                                                                                                                                                                                                                                           | 10         |
|       |            | Light Failure Sensor, Rear Lights Warning                                                                                                                                                                                                                                                                                                                | 11, 12     |
|       |            | Defogger S/W, Defogger Relay                                                                                                                                                                                                                                                                                                                             | 14         |
|       |            | Power Window Main Relay                                                                                                                                                                                                                                                                                                                                  | 18         |
|       |            | A/T Indicator S/W, Pattern Select S/W                                                                                                                                                                                                                                                                                                                    | 21         |
|       |            | A.B.S. Warning Light, A.B.S. Computer                                                                                                                                                                                                                                                                                                                    | 22         |
|       |            | Seat Belt Warning Light, Integration Relay No. 1                                                                                                                                                                                                                                                                                                         | 26         |
|       |            | Super Monitor Computer                                                                                                                                                                                                                                                                                                                                   | 27         |
|       |            | Combination Meter                                                                                                                                                                                                                                                                                                                                        | 32         |
|       |            | Heater Relay, Water Valve VSV, Heater Control Assembly, A/C Relay Box                                                                                                                                                                                                                                                                                    | 33         |
| 15A   | TAIL       | Glove Box Light, Combination Meter Light, Radio, A/T Indicator<br>Pattern Select S/W, Cruise Control Main S/W,<br>Hazard S/W, O/D Main S/W, Defogger S/W<br>Cigarette Lighter, Heater Control Assembly, Fog Light S/W<br>Clearance Lights, Front Side Marker Lights,<br>Licence Plate Lights, Rear Side Marker Lights<br>Light Failure Sensor, Taillight | 12         |
|       |            | Clock                                                                                                                                                                                                                                                                                                                                                    | 24         |
|       |            | Super Monitor Computer                                                                                                                                                                                                                                                                                                                                   | 27         |
| 15A   | ECU-IG     | Light Retainer Relay (Integration Relay No. 2)                                                                                                                                                                                                                                                                                                           | 5          |
|       |            | Cruise Control Main S/W                                                                                                                                                                                                                                                                                                                                  | 20         |
|       |            | ECT ECU                                                                                                                                                                                                                                                                                                                                                  | 21         |
|       |            | A.B.S. Computer                                                                                                                                                                                                                                                                                                                                          | 22         |
|       |            | TEMS Computer, TEMS S/W                                                                                                                                                                                                                                                                                                                                  | 25         |
|       |            | Auto Antenna                                                                                                                                                                                                                                                                                                                                             | 30         |
| 7.5A  | RADIO NO.2 | Remote Control Mirror S/W, Mirror Motor                                                                                                                                                                                                                                                                                                                  | 13         |
|       |            | Radio and Tape Player                                                                                                                                                                                                                                                                                                                                    | 31         |
| 7.5A  | DOME       | Vanity Mirror Light, Ignition Key Cylinder Light, Interior Light, Door Key<br>Cylinder Light, Door Warning Light, Luggage Compartment Light, Integration<br>Relay No. 1, Door Courtesy Light                                                                                                                                                             | 9          |
|       |            | Integration Relay No.1                                                                                                                                                                                                                                                                                                                                   | 26         |
| 10A   | MIR. HTR   | Mirror Heater                                                                                                                                                                                                                                                                                                                                            | 14         |

**J/B No.1 (Left Kick Panel)**

| Power |          | Load                     | System No. |
|-------|----------|--------------------------|------------|
| 15A   | ENGINE   | Alternator               | 4          |
| 15A   | CIG      | Cigarette Lighter, Clock | 24         |
|       |          | Super Monitor Computer   | 27         |
|       |          | Theft Deterrent Computer | 29         |
|       |          | Auto Antenna             | 30         |
|       |          | Magnet Clutch Relay      | 33         |
| 30A   | DEFOG CB | Rear Window Defogger     | 14         |

**J/B No.2 (Engine Compartment)**

|       |                    |                                                                                                                            |    |
|-------|--------------------|----------------------------------------------------------------------------------------------------------------------------|----|
| 30A   | RTR                | Retract Control Relay (Integration Relay No. 2)                                                                            | 7  |
| 7.5A  | CHARGE             | Alternator                                                                                                                 | 4  |
| 15A   | HEAD LH            | Headlight (LH)                                                                                                             | 7  |
| 15A   | HEAD RH            | Headlight (RH)                                                                                                             | 7  |
| 15A   | HAZ-HORN           | Turn Signal Flasher                                                                                                        | 16 |
|       |                    | Horns, Horn Relay                                                                                                          | 28 |
|       |                    | Theft Deterrent Horn                                                                                                       | 29 |
| 15A   | EFI                | Circuit Opening Relay, TCCS ECU, Check Connector, ISC Valve, VSV (EGR, Fuel Pressure up and Intake Air Control), OX Sensor | 3  |
| 15A   | RADIO NO. 1        | ECT ECU                                                                                                                    | 21 |
|       |                    | Clock                                                                                                                      | 24 |
|       |                    | Super Monitor Computer                                                                                                     | 27 |
|       |                    | Theft Deterrent Computer                                                                                                   | 29 |
|       |                    | Auto Antenna                                                                                                               | 30 |
|       |                    | Radio and Tape Player                                                                                                      | 31 |
| 30A   | FL AM <sub>2</sub> | Ignition S/W (AM <sub>2</sub> )                                                                                            | 1  |
| 30A   | FL CDS FAN         | Condenser Fan Motor                                                                                                        | 33 |
| 40A   | FL AM <sub>1</sub> | Ignition S/W (AM <sub>1</sub> )                                                                                            | 1  |
|       |                    | Alternator                                                                                                                 | 4  |
|       |                    | Headlight Cleaner Motor                                                                                                    | 23 |
| 1.25B | FL ALT             | Alternator                                                                                                                 | 4  |
| 60A   | FL ESC             | A.B.S. Actuator, A.B.S. Computer                                                                                           | 22 |

**J/B No.4 (Right Kick Panel)**

|     |           |                                                                     |    |
|-----|-----------|---------------------------------------------------------------------|----|
| 10A | A/C       | A/C Amplifier Dual Pressure S/W, Condenser Fan Relay, Magnet Clutch | 33 |
| 30A | HEATER CB | Blower Motor                                                        | 33 |

**Fusible Links (Near the Battery)**

|         |  |                 |      |
|---------|--|-----------------|------|
| FL 2.0L |  | Headlight Relay | 1, 7 |
|---------|--|-----------------|------|

**J/B No.5 (Near the J/B No.1)**

|     |        |                               |    |
|-----|--------|-------------------------------|----|
| 30A | PWR CB | Door Lock Control Relay       | 16 |
|     |        | Power Window Master S/W       | 18 |
|     |        | Power Seat S/W, Support Motor | 19 |

**Fuse (Near the J/B No.1)**

|     |           |                                  |   |
|-----|-----------|----------------------------------|---|
| 15A | FRONT FOG | Front Fog Light, Fog Light Relay | 8 |
|-----|-----------|----------------------------------|---|





**TAILLIGHT RELAY**

CLOSED WITH LIGHT CONTROL S/W AT TAIL OR HEAD POSITION

**HEADLIGHT RELAY**


CLOSED WITH LIGHT CONTROL S/W AT HEAD POSITION

OR DIMMER S/W AT FLASH POSITION


**① IGNITION S/W**

4-3 : CLOSED WITH IGNITION KEY AT ACC OR IG POSITION


8-7, 4-2: CLOSED WITH IGNITION KEY AT IG OR ST POSITION

**① BLACK**









(J/B NO.2)


**②**


(R/B NO.4)

**③**

(R/B NO.5)

**④ BLACK****⑤****①A BLACK****①J****①K****②A BLACK****②B BLACK****②D****②E****A4**





## (A) IGNITION S/W

4-1: CLOSED WITH IGNITION S/W AT ST POSITION

8-7: CLOSED WITH IGNITION S/W AT IG OR ST POSITION

## (B) STARTER RELAY

2-4: CLOSED WITH CLUTCH START S/W ON AND IGNITION S/W AT ST POSITION

## (C) CLUTCH START S/W (M/T)

2-1: CLOSED WITH CLUTCH PEDAL FULLY DEPRESSED

## STARTER

POINTS CLOSED WITH CLUTCH START S/W ON AND IGNITION S/W AT ST POSITION

## (F) NEUTRAL START S/W (A/T)

1-2, 2-3: CLOSED WITH A/T SHIFT LEVER IN P OR N POSITION

## (G) COLD START INJECTOR

2-1: 12 VOLTS WHILE START INJECTOR TIME S/W IS CLOSED AND STARTER CRANKING

## (H) START INJECTOR TIME S/W


POINTS OPEN ABOVE 22°C (72°F)

2-1: APPROX. 30-50Ω BELOW 22°C (72°F)


2-1: APPROX. 70-90Ω ABOVE 22°C (72°F)

2-GROUND: APPROX. 30-90Ω


(A) BLACK




(C)



(D) GREEN




(E) BLACK




(J/B NO. 2)


(F)




(G) BLACK



(H) BROWN




(I)



(J) GREEN



(K) (T) YELLOW




(L)



(M) BROWN




(N) (V)




(O) (Q) (R) GREEN




(P) GREEN




(S) YELLOW




(U) BLACK




(1A) BLACK




(1I)



(1J)







(1M)




(2A) BLACK












# 3-1 EFI SYSTEM(7M-GTE)



**EFI MAIN RELAY**

CLOSED WITH IGNITION S/W AT IG OR ST POSITION

**(B) EFI RESISTOR**1-2, 2-3, 2-4: EACH 2  $\Omega$ **(C) INJECTOR**1-2: EACH 1.5-3.0  $\Omega$ **(D) STARTER RELAY**2-4: CLOSED WITH CLUTCH PEDAL FULLY DEPRESSED  
AND IGNITION S/W AT ST POSITION**(E) CIRCUIT OPENING RELAY**1-2: CLOSED WITH STARTER RUNNING OR  
MEASURING PLATE (AIR FLOW METER) OPEN**(I) FUEL PUMP RESISTOR**1-2: APPROX. 0.7  $\Omega$ **(J) AIR FLOW METER**1-2: 10-20 K  $\Omega$  (-20°C, -4°F)4-7 K  $\Omega$  (0°C, 32°F)2-3 K  $\Omega$  (20°C, 68°F)0.9-1.3 K  $\Omega$  (40°C, 104°F)0.4-0.7 K  $\Omega$  (60°C, 140°F)**(L) THROTTLE POSITION SENSOR**2-4: 0.3-6.3 K  $\Omega$  WITH CLEARANCE BETWEEN  
LEVER AND STOP SCREW 0MM (0IN.)3-4: LESS THAN 2.3 K  $\Omega$  WITH CLEARANCE BETWEEN  
LEVER AND STOP SCREW 0.40MM (0.0157IN)  
 $\infty \Omega$  WITH 0.75MM (0.0295IN)2-4: 3.5-10.3 K  $\Omega$  WITH THROTTLE VALVE FULLY OPEN1-4: 4.25-8.25 K  $\Omega$ **(O) ISC VALVE**2-1, 3: EACH 10-30  $\Omega$ 1-2, 4: EACH 10-30  $\Omega$ **(Q) WATER THERMO SENSOR**1-2: APPROX. 6 K  $\Omega$  (0°C, 32°F)APPROX. 1.5 K  $\Omega$  (40°C, 104°F)APPROX. 0.5 K  $\Omega$  (80°C, 176°F)**TCCS ECU (ELECTRONIC CONTROLLED UNIT)**

VOLTAGE AT ECU CONNECTORS

(R) 2-(U) 7: 10-14 VOLTS

(R) 13, (R) 14-(U) 7: 10-14 VOLTS (IGNITION S/W ON)

(R) 1-(U) 7: 10-14 VOLTS (IGNITION S/W ON)

(R) 9-(U) 7: 10-14 VOLTS (IGNITION S/W ON)

(T) 13-(R) 24: 4-6 VOLTS (IGNITION S/W ON,  
THROTTLE VALVE OPEN)(T) 14-(R) 24: 0.1-5 VOLTS (IGNITION S/W ON,  
THROTTLE VALVE CLOSED TO OPEN)

(T) 3-(R) 24: 4-6 VOLTS (IGNITION S/W ON)

(T) 4-(R) 24: 4-5 VOLTS (IGNITION S/W ON,  
MEASURING PLATE FULLY CLOSED)  
0.02-0.08 VOLTS (IGNITION S/W ON,  
MEASURING PLATE FULLY OPEN)  
2.0-4.0 VOLTS (IDLING)  
0.3-1.0 VOLTS (3000 RPM)(R) 5-(R) 24: 1.0-3.0 VOLTS (IGNITION S/W ON,  
INTAKE AIR TEMP. 20°C (68°F))(T) 1-(R) 24: 0.1-1.0 VOLT (IGNITION S/W ON,  
COOLANT TEMP. 80°C (176°F))

(U) 3-(U) 7

: 6-14 VOLTS

(IGNITION S/W ST POSITION)

(U) 4, (U) 8, (U) 9-(U) 7

: 9-14 VOLTS (IGNITION S/W ON)

(T) 3-(U) 7

: 0.7-1.0 VOLTS (IDLING)

(T) 8, (T) 9, (T) 17, (T) 18-(U) 7: 9-14 VOLTS (IGNITION S/W ON)  
9-14 VOLTS

(2-3 SECONDS AFTER ENGINE OFF)

(T) 1-(T) 7

: 0 VOLT WITH IGNITION S/W ON,

SHIFT POSITION P OR N RANGE

10-14 VOLTS WITH IGNITION S/W ON,

SHIFT POSITION EXCEPT P OR N RANGE

0 VOLT WITH IGNITION S/W ON,

CLUTCH PEDAL NOT DEPRESSED

10-14 VOLTS WITH IGNITION S/W ON,

CLUTCH PEDAL DEPRESSED

9-11 VOLTS WITH CRANKING

(R) 15-(T) 7

: 4-6 VOLTS WITH IGNITION S/W ON,

CHECK CONNECTOR T-E1 NOT SHORT

0 VOLT WITH IGNITION S/W ON,

CHECK CONNECTOR T-E1 SHORT

(R) 20-(U) 7

: 10-14 VOLTS WITH IGNITION S/W ON

A/C S/W ON

0 VOLT WITH IGNITION S/W ON

A/C S/W OFF

(T) 16-(U) 7

: 0  $\leftrightarrow$  5 VOLTS WITH ENGINE START

(THROTTLE VALVE OPEN)

(R) 19-(U) 7

: 0 VOLT WITH IGNITION S/W ON

: 10-13 VOLTS WITH ENGINE START

(R) 18-(U) 7

: 10-14 VOLTS WITH IGNITION S/W ON

DEFROGGER S/W OFF

0 VOLT WITH IGNITION S/W ON

DEFROGGER S/W ON

(R) 16-(U) 7

: 10-14 VOLTS WITH HEADLIGHT S/W OFF


0 VOLT WITH HEADLIGHT S/W ON

**RESISTANCE AT ECU CONNECTOR**


(DISCONNECT WIRING CONNECTOR FROM ECU)

(T) 13-(R) 24:  $\infty \Omega$  (THROTTLE VALVE FULLY OPEN)LESS THAN 2.3 K  $\Omega$  (THROTTLE VALVE FULLY CLOSED)(T) 14-(R) 24: 3500-10300  $\Omega$  (THROTTLE VALVE FULLY OPEN)300-6300  $\Omega$  (THROTTLE VALVE FULLY CLOSED)(R) 3-(R) 24: 200-400  $\Omega$ (R) 4-(R) 24: 20-600  $\Omega$  (MEASURING PLATE FULLY CLOSED)20-3000  $\Omega$  (MEASURING PLATE FULLY OPEN)(R) 5-(R) 24: 2000-3000  $\Omega$  (INTAKE AIR TEMP. 20°C, 68°F)(T) 5, (T) 6, (T) 4-(T) 7: 140-180  $\Omega$ (T) 8, (T) 9, (T) 17, (T) 18-(R) 14: 10-30  $\Omega$

(A) BLACK





(B) (G) YELLOW



(C) GRAY



(E)



(H) YELLOW



(I) YELLOW




(J) BLACK



(K) YELLOW




(L) BLACK




(M) GREEN




(N) BLACK




(O) GRAY




(P) BLACK




(Q) GREEN




(R) YELLOW




(S) YELLOW



(T) YELLOW



(U) YELLOW




(V) (W) BROWN



(X) (Y) (A) GREEN




(Z) GREEN




(B) BLUE




(C) BLUE



(D) GRAY



(1B)



(1F)







1G

1I



1J 2F

1M





3B BLUE

B1 YELLOW



B2




C1



E2



E3 BLUE


G1 YELLOW



M1 YELLOW


N1







# 3-2 EFI SYSTEM(7M-GE)





**EFI MAIN RELAY**

CLOSED WITH IGNITION S/W AT IG OR ST POSITION

**ⓑ EFI RESISTOR**

1-2, 2-3, 2-4: EACH 2Ω

**ⓒ INJECTOR**

1-2: EACH 1.5-3.0Ω

**ⓓ STARTER RELAY**2-4: CLOSED WITH CLUTCH PEDAL FULLY DEPRESSED  
AND IGNITION S/W AT ST POSITION**ⓕ CIRCUIT OPENING RELAY**1-2: CLOSED WITH STARTER RUNNING OR  
MEASURING PLATE (AIR FLOW METER) OPEN**ⓖ FUEL PUMP RESISTOR**

1-2: APPROX. 0.7Ω

**ⓗ AIR FLOW METER**1-2: CLOSED WITH STARTER RUNNING OR  
MEASURING PLATE OPEN

5-6: 20-400Ω

5-4: 200-400Ω

10-20KΩ (-20°C, -4°F)

4-7KΩ (0°C, 32°F)

2-3KΩ (20°C, 68°F)

0.9-1.3KΩ (40°C, 104°F)

0.4-0.7KΩ (60°C, 140°F)

**Ⓢ THROTTLE POSITION SENSOR**2-4: 0.3-6.3KΩ WITH CLEARANCE BETWEEN  
LEVER AND STOP SCREW 0MM (0IN.)3-4: LESS THAN 2.3KΩ WITH CLEARANCE BETWEEN  
LEVER AND STOP SCREW 0.40MM (0.0157IN)  
∞Ω WITH 0.75MM (0.0295IN)

2-4: 3.5-10.3KΩ WITH THROTTLE VALVE FULLY OPEN

1-4: 4.25-8.25KΩ

**Ⓣ ISC VALVE**

2-1, 3: EACH 10-30Ω

1-2, 4: EACH 10-30Ω

**Ⓟ WATER THERMO SENSOR**

1-2: APPROX. 6KΩ (0°C, 32°F)

APPROX. 1.5KΩ (40°C, 104°F)

APPROX. 0.5KΩ (80°C, 176°F)

**TCCS ECU (ELECTRONIC CONTROLLED UNIT)**

VOLTAGE AT ECU CONNECTORS

ⓐ 2-Ⓢ 7: 10-14VOLTS

ⓐ 13, ⓐ 14-Ⓢ 7: 10-14VOLTS (IGNITION S/W ON)

ⓐ 1-Ⓢ 7: 10-14VOLTS (IGNITION S/W ON)

ⓐ 9-Ⓢ 7: 10-14VOLTS (IGNITION S/W ON)

Ⓡ 13-ⓐ 24: 4-6VOLTS (IGNITION S/W ON,  
THROTTLE VALVE OPEN)Ⓡ 14-ⓐ 24: 0.1-5VOLTS (IGNITION S/W ON,  
THROTTLE VALVE CLOSED TO OPEN)

Ⓡ 3-ⓐ 24: 4-6VOLTS (IGNITION S/W ON)

Ⓡ 4-ⓐ 24: 4-5VOLTS (IGNITION S/W ON,  
MEASURING PLATE FULLY CLOSED)  
0.02-0.08VOLTS (IGNITION S/W ON,  
MEASURING PLATE FULLY OPEN)  
2.0-4.0VOLTS (IDLING)  
0.3-1.0VOLTS (3000 RPM)ⓐ 5-ⓐ 24: 1.0-3.0VOLTS (IGNITION S/W ON,  
INTAKE AIR TEMP. 20°C (68°F))Ⓡ 1-ⓐ 24: 0.1-1.0VOLT (IGNITION S/W ON,  
COOLANT TEMP. 80°C (176°F))

Ⓢ 3-Ⓢ 7

: 6-14VOLTS  
(IGNITION S/W ST POSITION)

Ⓢ 4, Ⓢ 8, Ⓢ 9-Ⓢ 7

: 9-14VOLTS (IGNITION S/W ON)

Ⓡ 3-Ⓢ 7

: 0.7-1.0VOLTS (IDLING)

Ⓡ 8, Ⓡ 9, Ⓡ 17, Ⓡ 18-Ⓢ 7

: 9-14VOLTS (IGNITION S/W ON)  
9-14VOLTS  
(2-3 SECONDS AFTER ENGINE OFF)

Ⓡ 1-Ⓡ 7

: 0VOLT WITH IGNITION S/W ON,  
SHIFT POSITION P OR N RANGE  
10-14VOLTS WITH IGNITION S/W ON,  
SHIFT POSITION EXCEPT P OR N RANGE  
0VOLT WITH IGNITION S/W ON,  
CLUTCH PEDAL NOT DEPRESSED  
10-14VOLTS WITH IGNITION S/W ON,  
CLUTCH PEDAL DEPRESSED  
9-11VOLTS WITH CRANKING

ⓐ 15-Ⓡ 7

: 4-6VOLTS WITH IGNITION S/W ON,  
CHECK CONNECTOR T-E1 NOT SHORT  
0VOLT WITH IGNITION S/W ON,  
CHECK CONNECTOR T-E1 SHORT

ⓐ 20-Ⓢ 7

: 10-14VOLTS WITH IGNITION S/W ON  
A/C S/W ON  
0VOLT WITH IGNITION S/W ON  
A/C S/W ON

Ⓡ 16-Ⓢ 7

: 0↔5VOLTS WITH ENGINE START  
(THROTTLE VALVE OPEN)

ⓐ 19-Ⓢ 7

: 0VOLT WITH IGNITION S/W ON  
10-13VOLTS WITH ENGINE START

ⓐ 18-Ⓢ 7

: 10-14VOLTS WITH IGNITION S/W ON  
DEFOGGER S/W OFF  
0VOLT WITH IGNITION S/W ON  
DEFOGGER S/W ON

ⓐ 16-Ⓢ 7

: 10-14VOLTS WITH HEADLIGHT S/W ON  
0VOLT WITH HEADLIGHT S/W ON**RESISTANCE AT ECU CONNECTOR**

(DISCONNECT WIRING CONNECTOR FROM ECU)

Ⓡ 13-ⓐ 24: ∞Ω (THROTTLE VALVE FULLY OPEN)  
LESS THAN 2.3KΩ (THROTTLE VALVE FULLY CLOSED)Ⓡ 14-ⓐ 24: 3500-10300Ω (THROTTLE VALVE FULLY OPEN)  
300-6300Ω (THROTTLE VALVE FULLY CLOSED)


ⓐ 3-ⓐ 24: 200-400Ω

ⓐ 4-ⓐ 24: 20-600Ω (MEASURING PLATE FULLY CLOSED)  
20-3000Ω (MEASURING PLATE FULLY OPEN)


ⓐ 5-ⓐ 24: 2000-3000Ω (INTAKE AIR TEMP. 20°C, 68°F)

Ⓡ 5, Ⓡ 6, Ⓡ 4-Ⓡ 7: 140-180Ω

Ⓡ 8, Ⓡ 9, Ⓡ 17, Ⓡ 18-ⓐ 14: 10-30Ω




1B




1F




1G




1I




1J




1M




2F




3B BLUE




B1 YELLOW




B2




C1




E2




E3 BLUE




G1 YELLOW




M1 YELLOW



N1



# 4 CHARGING SYSTEM



**ALTERNATOR**

Ⓒ 1-GROUND: 13.5-15.1 VOLTS WITH ENGINE RUNNING AT 2000RPM





Ⓒ 2-GROUND: 0-4 VOLTS WITH IGNITION S/W AT IG POSITION AND ENGINE NOT RUNNING

Ⓐ BLACK

Ⓑ BROWN

Ⓒ BLACK

Ⓓ






(J/B NO.2)

ⓐ

ⓑ



Ⓐ BLACK

Ⓑ BLACK





Ⓓ

Ⓔ





Ⓐ

Ⓐ



Ⓐ





# **① INTEGRATION RELAY NO.2**

2-GROUND, 10-GROUND: APPROX. 12 VOLTS WITH LIGHT CONTROL S/W OFF

(HEADLIGHT, TAILLIGHT OFF)


10-GROUND : 0 VOLT WITH LIGHT CONTROL S/W A/T HEAD POSITION (TAILLIGHTS ON)  
(HEADLIGHTS ON)

2-GROUND : 0 VOLT WITH LIGHT CONTROL S/W A/T TAIL POSITION (TAILLIGHTS ON)


2-GROUND, 10-GROUND: 0 VOLT WITH LIGHT CONTROL S/W A/T HEAD, TAIL POSITION AFTER  
IGNITION S/W TURNED OFF AND LH DOOR OPEN  
(HEADLIGHT, TAILLIGHT OFF)

(HEADLIGHT, TAILLIGHT TURN OFF AUTOMATICALLY WHEN THE IGNITION S/W  
IS TURNED OFF AND LH DOOR OPEN)

①




② BLACK



(J/B NO.2)


③ BLACK




④ BLUE




①A BLACK




①B




①D




①L



①M




①N




②A BLACK




②B BLACK




⑦C BROWN



⑦D









# ③ TURN SIGNAL FLASHER

3-GROUND: 12VOLTS WITH IGNITION S/W ON OR HAZARD S/W ON  
 1-GROUND: CHANGES FROM 12 TO 0 VOLTS WITH IGNITION S/W ON  
 AND TURN SIGNAL S/W LEFT OR RIGHT, OR WITH HAZARD  
 S/W ON

① BLACK



② BLACK






③

④

⑤

⑥ GRAY




⑦



⑧B

⑩D

①F







⑩G

①K




①M

②B BLACK



③B BLUE






①D




①E ④E

②E

③E BLUE



(R/B NO.5)



### © RETRACT CONTROL RELAY

8-GROUND: ALWAYS 12VOLTS

1-18 : CONTINUITY FOR 8-12SECONDS WITH LIGHT CONTROL S/W AT HEAD POSITION OR LIGHT CONTROL S/W AT HOLD POSITION AND DIMMER S/W AT FLASH POSITION

1-18 : CONTINUITY FOR 8-12SECONDS 1-1.5SECONDS AFTER LIGHT CONTROL S/W OFF AND DIMMER S/W AT FLASH POSITION

9-18 : CONTINUITY FOR 8-12SECONDS WITH LIGHT CONTROL S/W AT HOLD(UP POSITION) → OFF POSITION

9-18 : CONTINUITY FOR 8-12SECONDS 1-1.5SECONDS AFTER LIGHT CONTROL S/W OFF AND DIMMER S/W AT FLASH POSITION

8-6,8-16: CLOSED WITH LIGHT CONTROL S/W AT HEAD POSITION UNTIL RETRACT MOTOR AT UP POSITION

8-6,8-16: CLOSED WITH LIGHT CONTROL S/W AT OFF POSITION UNTIL RETRACT MOTOR AT DOWN POSITION

### ⓓ RETRACT MOTOR


4-3 : OPEN WITH RETRACT MOTOR AT LOWERMOST POSITION

4-5 : OPEN WITH RETRACT MOTOR AT UPPERMOST POSITION

### LIGHT AUTO TURN-OFF OPERATION


PLEASE REFFER TO THE LIGHT AUTO TURN OFF SYSTEM (SYSTEM NO.5)

Ⓐ BLACK




(J/B NO.2)


Ⓑ BROWN




Ⓒ




Ⓓ BLACK




Ⓔ BLACK




Ⓕ GRAY




Ⓖ




Ⓗ BLACK




ⓁⒷ




ⓁⒻ




ⓁⒼ



ⓁⓁ




ⓁⓂ




2Ⓐ BLACK




2Ⓑ BLACK





2Ⓓ





**3B** BLUE





**A1**





**A2** YELLOW




**E2**



**E3** BLUE















## Ⓒ DIMMER S/W (COMB. S/W)


9-12: CLOSED WITH DIMMER S/W AT HIGH OR FLASH POSITION

## Ⓔ FOG LIGHT RELAY

2-4: CLOSED WITH LIGHT CONTROL S/W AT HEAD POSITION, DIMMER S/W AT LOW POSITION AND FOG LIGHT S/W ON



# 9 INTERIOR LIGHTS





# **INTEGRATION RELAY NO.1 (J/B NO.1)**

**(1G) 7-GROUND** : APPROX. 12VOLTS WITH DOOR CLOSED  
0VOLT WITH ANY DOOR OPEN

**7.5A DOME FUSE**: ALWAYS 12VOLTS

**(1I) 3-GROUND** : APPROX. 12VOLTS WITH DRIVER'S DOOR  
OUTSIDE HANDLE HOLD UP

**(1L) 7-GROUND** : APPROX. 12VOLTS WITH DOOR CLOSED  
0VOLT WITH ANY DOOR OPEN

0VOLT → 12VOLTS WITHIN 8.5 SECONDS AFTER DOOR CLOSED  
OR AFTER DRIVER'S DOOR OUTSIDE HANDLE HOLD UP

**(H) OUTSIDE HANDLE S/W (DRIVER'S DOOR)**



1-3 : CLOSED WITH DRIVER'S DOOR OUTSIDE HANDLE HOLD UP

**(I) DOOR COURTESY S/W**

1-GROUND : CLOSED WITH DOOR OPEN


**(J) BACK DOOR COURTESY S/W**

1-GROUND : CLOSED WITH BACK DOOR OPEN




# 9 INTERIOR LIGHTS


1K




1L




1N




7A ORANGE




7B BLUE




7C BROWN




7D




E2




E3 BLUE




F1 BLUE




F2 BLUE




G1 YELLOW




I1




P1 BLUE




R1





(A/T) (A)




(M/T) (B)




(M/T) (C)



(A/T) (D)




(E)




(1F)




(3B) BLUE




(E3) BLUE




(H1) GREEN



(M1) YELLOW





## © LIGHT FAILURE SENSOR

(DISCONNECT THE FAILURE SENSOR AND INSPECT THE CONNECTOR)





7-GROUND: 12VOLTS WITH STOP LIGHT S/W ON










3-GROUND: 12VOLTS WITH ENGINE RUNNING

2-GROUND: 12VOLTS WITH IGNITION S/W ON


9-GROUND: CONTINUITY


1-GROUND: CONTINUITY






# 12 TAILLIGHTS AND ILLUMINATION









**TAILLIGHT RELAY**

CLOSED WITH LIGHT CONTROL S/W AT TAIL OR HEAD POSITION  
(LIGHT RETAINER RELAY ON)

**(B) INTEGRATION RELAY NO.2**

PLEASE REFER TO LIGHT AUTO TURN OFF SYSTEM  
(SYSTEM NO.5)

**(M) RHEOSTAT**

3-4: 12VOLTS WITH RHEOSTAT FULLY TURNED COUNTERCLOCKWISE  
AND 0VOLT WITH FULLY TURNED CLOCKWISE

**(X) LIGHT FAILURE SENSOR**

(DISCONNECT THE FAILURE SENSOR AND INSPECT THE CONNECTOR)


10-GROUND : 12 VOLTS WITH IGNITION S/W ON, LIGHT CONTROL S/W AT  
TAIL OR HEAD POSITION

3-GROUND : 12 VOLTS WITH ENGINE RUNNING

















2-GROUND : 12 VOLTS WITH IGNITION S/W ON

9-GROUND : CONTINUITY

4-GROUND : CONTINUITY


**(A) BLACK**

(J/B NO.2)


**(B)****(C) BLACK****(D) BLACK****(E) BLACK****(F)****(G)****(H)****(I) GRAY****(J) BLUE****(K) BLACK****(L) BLUE****(M) BLUE****(N)****(O)****(P)****(Q) BLUE****(R)****(S)****(T)****(U)****(V)****(W)****(X)**

# 12 TAILLIGHTS AND ILLUMINATION


1A BLACK




1B




1D




1F




1L




1M




1N




3A




3B BLUE




3C ORANGE




E3 BLUE



H1 GREEN






## ① REMOTE CONTROL MIRROR S/W

1-GROUND: 12VOLTS WITH IGNITION S/W AT ACC OR IG POSITION


3-4 : CONTINUITY WITH OPERATION S/W AT UP OR LEFT POSITION

1-3 : CONTINUITY WITH OPERATION S/W AT DOWN OR RIGHT POSITION

① BLUE




②





①F




③A




E1 E4





E3 BLUE




F2 BLUE



P1 BLUE



# 14 REAR WINDOW DEFOGGER AND MIRROR HEATER



**DEFØGGER RELAY**

















CLOSED WITH IGNITION S/W ON. DEFØGGER S/W ON  
AND 15 MINUTES THEREAFTER

**DEFØGGER S/W (W/ TIMER)**


3- GROUND: 12 VOLTS WITH IGNITION S/W ON

4- GROUND: ALWAYS CONTINUITY

5-4 : CONTINUITY WITH DEFØGGER S/W ON AND  
15 MINUTES THEREAFTER



# 15 FRONT WIPERS AND WASHER











**⑧ WIPER AND WASHER S/W**


- 6-14 : APPROX. 50K $\Omega$  (SLOW)  
 APPROX. 0K $\Omega$  (FAST)
- 18-GROUND: 12 VOLTS WITH IGNITION S/W  
 AT IG POSITION
- 7-18 : CONTINUITY WITH WIPER S/W  
 AT LOW POSITION
- 13-18 : CONTINUITY WITH WIPER S/W  
 AT HIGH POSITION
- 4-2 : CONTINUITY WITH WIPER S/W  
 AT INT POSITION

**⑨ WIPER RELAY**

- 5-GROUND : 12 VOLTS WITH IGNITION S/W  
 AT IG POSITION
- 1-GROUND : 12 VOLTS 2-10 SECONDS INTERMITTENTLY  
 WITH IGNITION S/W ON AND WIPER S/W AT  
 INT POSITION
- 1-GROUND : 12 VOLTS WITH IGNITION S/W ON AND WASHER S/W ON  
 AND FOR 2.5 SECONDS AFTER WASHER S/W OFF

**⑨ WIPER RELAY****⑩ BLACK****⑪ BLACK****⑫****⑬****⑭****⑮****N1**







10-GROUND: ALWAYS CONTINUITY

4-GROUND : 12 VOLTS 0.2 SECONDS WITH FOLLOWING OPERATION

DOOR LOCK CONTROL S/W LOCKED

DOOR LOCK CYLINDER LOCKED WITH KEY

3-GROUND : 12 VOLTS 0.2 SECONDS WITH FOLLOWING OPERATION

DOOR LOCK CONTROL S/W UNLOCKED

DOOR LOCK CONTROL S/W LOCKED WITH IGNITION KEY IN

CYLINDER AND DRIVER'S DOOR OPEN

(IGNITION KEY REMINDER FUNCTION)

DOOR LOCK LEVER PUSHED WITH IGNITION KEY IN

CYLINDER AND DRIVER'S DOOR OPEN

(IGNITION KEY REMINDER FUNCTION)

UNLOCKING THE DRIVER'S, ASSISTANT'S DOOR CYLINDER WITH KEY

6-GROUND : 12→0VOLT WITH DOOR LOCK CONTROL S/W LOCKED OR

DRIVER'S, ASSISTANT'S DOOR LOCK CYLINDER LOCKED  
WITH KEY

9-GROUND : 12 VOLTS WITH DRIVER'S DOOR LOCK LEVER PUSHED

0 VOLT WITH DRIVER'S DOOR LOCK LEVER PULLED

11-GROUND: 12 VOLTS WITH ASSISTANT'S

DOOR LOCK LEVER PUSHED

OVOLT WITH ASSISTANT'S

DOOR LOCK LEVER PULLED  
12-GROUND: 12VOLTS WITH THE KEY REMOVED FROM THE IGNITION S/W

DRIVER'S DOOR CLOSED

0 VOLT WITH IGNITION KEY CYLINDER AND

DRIVER'S DOOR OPEN

13-GROUND: 12→0VOLT WITH DOOR LOCK CONTROL S/W UNLOCKED OR  
DRIVER'S, ASSISTANT'S DOOR LOCK

CYLINDER UNLOCKED WITH KEY

© UNLOCK WARNING S/W

1-2: CLOSED WITH IGNITION KEY IN CYLINDER

⑤ DOOR LOCK KEY S/W

3-2: CLOSED WITH DOOR LOCK CYLINDER LOCKED WITH KEY


1-2: CLOSED WITH DOOR LOCK CYLINDER UNLOCKED WITH KEY

⑥ DOOR LOCK SOLENOID

1-2: CLOSED WITH UNLOCK POSITION


⑨ DOOR COURTESY S/W

1-GROUND: CLOSED WITH DOOR OPEN







1D




1J




1K




1L




7A ORANGE




7D




F1 BLUE




F2 BLUE




G1 YELLOW




N1




P1 BLUE




P2 BLUE



R1







### © POWER WINDOW MASTER S/W

1-GROUND: 12VOLTS WITH IGNITION S/W AT IG POSITION


5-GROUND: ALWAYS CONTINUITY

2-GROUND: 12VOLTS WITH IGNITION S/W ON AND MASTER S/W  
(DRIVER'S WINDOW) UP






6-GROUND: 12VOLTS WITH IGNITION S/W ON AND MASTER S/W  
(DRIVER'S WINDOW) DOWN OR DOWNAUTO

### WINDOW LOCK S/W


OPEN WITH WINDOW LOCK S/W A/T LOCK POSITION




(R/B NO.5)










F1 BLUE




P1 BLUE















# A CRUISE CONTROL COMPUTER


(DISCONNECT THE COMPUTER CONNECTOR)

- 2-14 :  $\infty \Omega$  WITH BRAKE PEDAL DEPRESSED  
68  $\Omega$  WITH BRAKE PEDAL NOT DEPRESSED
- 4-14 : ALWAYS 30  $\Omega$  (ACTUATOR CONTROL VALVE)
- 7-13 : CONTINUITY EACH 40CM (15.7IN.) (DRIVE VEHICLE SLOWLY)
- 11-13 : CONTINUITY WITH CLUTCH PEDAL DEPRESSED  
(M/T) CONTINUITY WITH SHIFT LEVER IN  
N OR P RANGE (A/T) (ONE OF THE CANCEL S/W)
- 12-13 : CONTINUITY WITH PKB LEVER PULL UP (ONE OF THE CANCEL S/W)
- 13-GROUND: ALWAYS CONTINUITY
- 17-13 : 68  $\Omega$  WITH RESUME/ACCEL S/W ON  
198  $\Omega$  WITH SET/COAST S/W ON  
418  $\Omega$  WITH CANCEL S/W ON
- 9-GROUND: CONTINUITY WITH ENGINE VACUUM BELOW 170 MMHG (6.69IN•HG, 22.7 KPA)
- 3-13 : APPROX. 12VOLTS WITH IGNITION S/W ON, MAIN S/W ON
- 6-13 : 0VOLT WITH IGNITION S/W ON, COOLANT TEMP. BELOW 35°C (95°F)  
12VOLTS WITH IGNITION S/W ON, COOLANT TEMP. MORE THAN 55°C (131°F) (2S-E)  
5(12) VOLT(S) WITH IGNITION S/W ON, COOLANT TEMP. MORE THAN 70°C (158°F) (3S-G)  
( ): AISIN ECT COMPUTER
- 10-13 : 12VOLTS WITH IGNITION S/W ON, MAIN S/W ON
- 15-13 : 12VOLTS WITH BRAKE PEDAL DEPRESSED (ONE OF THE CANCEL S/W)
- 16-13 : ALWAYS 12VOLTS

A BLUE



B




C



D



E BLACK




F



G




H GRAY




I



J



K YELLOW




L



M




1B
















1F























1G














**7B** BLUE




**B1** YELLOW




**B2**




**E1**





**E3** BLUE



**E4**




**M1** YELLOW



(R/B NO. 4)




# 22 A. B. S. (ANTI-LOCK BRAKE SYSTEM)





# 22 A. B. S. (ANTI-LOCK BRAKE SYSTEM)

(A) BLACK




(J/B N0.2)


(B)




(C) BLACK




(D)




(E)




(F)



(G)



(H) BLUE




(I)



(J) (K)



(L)




(M)




(1F)




(1L)




(1N)




(3B) BLUE




(A2) YELLOW




(A3)




(A4)















(B1) YELLOW




(B2)









## Ⓐ CIGARETTE LIGHTER

2-GROUND: 12 VOLTS WITH IGNITION S/W  
AT IG OR ACC POSITION










## Ⓑ DIGITAL CLOCK


3-GROUND: ALWAYS 12 VOLTS  
(POWER FOR CLOCK)


4-GROUND: 12 VOLTS WITH IGNITION S/W  
AT IG OR ACC POSITION  
(POWER FOR INDICATION)

2-GROUND: 12 VOLTS WITH LIGHT CONTROL S/W  
AT TAIL OR HEAD POSITION  
(SIGNAL OF DIM INDICATION)

1-GROUND: ALWAYS CONTINUITY











## TEMS AND PPS COMPUTER

- (B) 3-GROUND: APPROX. 12 VOLTS FOR 0.2 SECONDS WITH IGNITION S/W ON, TURN MODE SELECT S/W FROM NORMAL TO SPORT  
(POWER FOR ACTUATOR MOTOR)
- (B) 4-GROUND: APPROX. 12 VOLTS WITH IGNITION S/W ON
- (B) 5-GROUND: APPROX. 12 VOLTS WITH IGNITION S/W ON, MODE SELECT S/W SPORT
- (B) 9-GROUND: APPROX. 12 VOLTS FOR 0.2 SECONDS WITH IGNITION S/W ON, TURN MODE SELECT S/W FROM SPORT TO NORMAL
- (B) 10-GROUND: APPROX. 12 VOLTS FOR 0.2 SECONDS WITH IGNITION S/W ON, CHECK CONNECTOR TEM-E2 SHORT AND  
TURN MODE SELECT S/W FROM NORMAL TO SPORT
- (C) 4-GROUND: 5→0→5→0→5 VOLTS
- (C) 5-GROUND: 5→0→5 VOLTS
- (C) 12-GROUND: 5→0 VOLT
- (C) 6-GROUND: APPROX. 3.7 VOLTS WITH IGNITION S/W ON
- (C) 7, (C) 8, (C) 9-GROUND: APPROX. 6.5 VOLTS FOR 2 SECONDS WITH IGNITION S/W ON
- (C) 10-GROUND: MORE THAN 6 VOLTS WITH BRAKE PEDAL DEPRESSED  
LESS THAN 1.5 VOLTS WITH BRAKE PEDAL NOT DEPRESSED
- (C) 11-GROUND: APPROX. 0 VOLT WITH SHIFT LEVER AT N OR P POSITION  
APPROX. 12 VOLTS WITH SHIFT LEVER AT EXCEPT N OR P POSITION


IGNITION S/W ON AND SLOWLY DEPRESS THE ACCELERATOR PEDAL




1L




1N




3A




3B BLUE




7A ORANGE




7B BLUE




A2 YELLOW




A3 C1




B1 YELLOW




D1




E1




E2 BLUE




E3 BLUE






E4




G1


YELLOW



Q1



R1





7.5A GAUGE FUSE: 12V WITH IGNITION S/W ON

© UNLOCK WARNING S/W

© UNLOCK WARNING S/W


2-1:CLOSED WITH IGNITION KEY IN CYLINDER (FOR UNLOCK WARNING)


④ BUCKLE S/W


1-2:CLOSED WITH DRIVER'S LAP BELT IN USE (FOR SEAT BELT WARNING)

⑤ DOOR COURTESY S/W(DRIVER)


1-GROUND: CLOSED WITH DRIVER'S DOOR OPEN (FOR UNLOCK WARNING)








Ⓕ BLUE



Ⓖ GREEN




Ⓗ




Ⓘ BLUE




Ⓙ




1Ⓑ




1Ⓖ




1Ⓙ




1Ⓐ




2Ⓑ BLACK




7Ⓐ ORANGE




7Ⓑ BLUE




B1 YELLOW




E1




E4



M1 YELLOW













**(A) HORN RELAY**  
2-4: CLOSED WITH HORN S/W ON

**(B) BLACK**

**(C) BLACK**





**A1**





# 29 THEFT DETERRENT SYSTEM





## (B) THEFT DETERRENT COMPUTER

- 1 -GROUND: 0 VOLT WITH LH OR RH DOOR LOCK LEVER PULLED  
12 VOLTS WITH LH OR RH DOOR LOCK LEVER PULLED
- 2 -GROUND: 12 VOLTS WITHIN 30 SECONDS WITH SYSTEM ON
- 3 -GROUND: 12 VOLTS WITH SYSTEM ON AND IGNITION S/W ST POSITION  
0 VOLT WITH SYSTEM OPERATED
- 4 -GROUND: 12 VOLTS WITH IGNITION S/W AT ACC. ON POSITIONS  
0 VOLT WITH IGNITION S/W OFF
- 5 -GROUND: ALWAYS 12 VOLTS
- 6 -GROUND: 0 VOLT WITH LH OR RH DOOR OPEN  
12 VOLTS WITH LH OR RH DOOR CLOSED
- 8 -GROUND: 0 VOLT WITH ENGINE HOOD OR BACK DOOR OPEN  
12 VOLTS WITH ENGINE HOOD AND BACK DOOR CLOSED
- 9 -GROUND: 0 VOLT WITH LH OR RH DOOR UNLOCKED WITH KEY  
12 VOLTS WITH LH OR RH DOOR LOCKED WITH KEY
- 10 -GROUND: ALWAYS CONTINUITY
- 11 -GROUND: 0 VOLT WITH BACK DOOR UNLOCKED WITH THE KEY  
12 VOLTS WITH BACK DOOR LOCKED WITH THE KEY
- 12 -GROUND: 12 VOLTS WITH SYSTEM OFF CHANGES 12 TO 0 VOLT  
WITH SYSTEM OPERATED

## (E)(F) DOOR LOCK S/W

- 1-2 : CLOSED WITH DOOR OPEN

## (G)(H) DOOR KEY S/W

- 1-3 : CLOSED WITH KEY CYLINDER UNLOCKED WITH KEY

## (I)(J) S/W IN DOOR LOCK SOLENOID

- 1-2 : CLOSED WITH DOOR LOCK LEVER PULLED

## (K) ENGINE HOOD COURTESY S/W



- 1-3 : CLOSED WITH ENGINE HOOD OPEN

## (L) BACK DOOR COURTESY S/W


- 1 -GROUND: CLOSED WITH DOOR OPEN

## (M) BACK DOOR KEY UNLOCK S/W


- 1-2 : CLOSED WITH BACK DOOR UNLOCKED WITH THE KEY




(C) BROWN




(D)



(E)(F)




(G)



(H)



(I)(J)



(K) BLACK




(L)




(M)




(N)




(O)



(1B)




(1G)




(1F)




(1K)




(1M)




(1N)




(2B) BLACK




(2F)




(3B) BLUE




(7A) ORANGE




(7B) BLUE




7C BROWN




7D




A1




B1 YELLOW




C1




E1




E3 BLUE




F1 BLUE




F2 BLUE



G1 YELLOW




N1




(R/B NO.4)


P1 BLUE




P2 BLUE











U1






### © CONTROL RELAY


- 3-GROUND: CONTINUITY (UPPER LIMIT S/W ON)  
UNLESS ANTENNA AT UP STOP
- 2-GROUND: CONTINUITY (DOWN LIMIT S/W ON)  
UNLESS ANTENNA AT DOWN STOP
- 4-3 : CLOSED WITH IGNITION S/W AT ACC OR  
IG POSITION AND RADIO S/W ON AND  
PLAYER S/W OFF UNTIL ANTENNA AT  
UPPERMOST POSITION
- 1-2 : CLOSED WITH IGNITION S/W AT ACC OR  
IG POSITION AND RADIO S/W OFF AND  
PLAYER S/W OFF UNTIL ANTENNA AT  
LOWERMOST POSITION
- 1-2 : CLOSED WITH IGNITION S/W OFF UNTIL  
ANTENNA AT LOWERMOST POSITION




E3 BLUE




G1 YELLOW




H1 GREEN



R1




# 31 RADIO AND TAPE PLAYER



A



B




C



D




1B




1F




1G




2B BLACK




E1 E4




E3 BLUE




F2 BLUE




H1 GREEN




P1 BLUE




R1









## COMBINATION METER

- (D) 2-GROUND: 12VOLTS WITH IGNITION S/W ON  
 (C) 8-GROUND: 12VOLTS WITH IGNITION S/W ON  
 (A) 3, (A) 8, (B) 5, (C) 6-GROUND: ALWAYS CONTINUITY

## FUEL LEVEL GAUGE

- (C) 8- (C) 4 : APPROX. 167.2Ω  
 (C) 8- (C) 6 : APPROX. 102.7Ω  
 (C) 4- (C) 6 : APPROX. 64.5Ω

## OIL PRESSURE GAUGE

- (C) 8- (D) 4 : APPROX. 42Ω

## WATER TEMP. GAUGE

- (C) 8- (A) 2 : APPROX. 56Ω  
 (C) 8- (A) 3 : APPROX. 145.8Ω  
 (A) 2- (A) 3 : APPROX. 201.8Ω

## (F) PARKING BRAKE S/W

1-GROUND: CLOSED WITH PARKING BRAKE  
LEVER PULLED UP

## (G) BRAKE FLUID LEVEL S/W

1-2 : CLOSED WITH FLOAT DOWN

## (K) FUEL SENDER


3-4 : APPROX. 4Ω WITH FUEL FULL  
 APPROX. 32.5Ω WITH FUEL HALF FULL  
 APPROX. 110.0Ω WITH FUEL EMPTY

## (M) WATER TEMP. SENDER


(NIPPON DENSO MAKE)

1-GROUND: APPROX. 226Ω AT 50°C(122°F)  
 APPROX. 26Ω AT 115°C(239°F)


(A)




(B) GRAY



(C) BLUE



(D) BROWN



(E)



(F) BLACK



(G) (J)



(H) GREEN



(I) GRAY



(K)




(L) BLACK




(M)




(1B)




(1F)




(3A)




(3B)




A1




A2 YELLOW




E1




E3 BLUE




E5




H1 GREEN



M1 YELLOW




# 33 AUTOMATIC AIR CONDITIONER



L-R

L-R


(E) HEATER CONTROL ASSEMBLY




L-P

G-6









## (B) HEATER RELAY

4-5: CLOSED WITH IGNITION S/W ON AND BLOWER S/W ON

## (D) BLOWER RESISTOR

6-3: APPROX. 0.22  $\Omega$

3-2: APPROX. 0.55  $\Omega$

2-1: APPROX. 0.90  $\Omega$

1-4: APPROX. 1.23  $\Omega$

## (E) HEATER CONTROL ASSEMBLY

1-10: ALWAYS 12VOLTS

2-10: 12VOLTS WITH IGNITION S/W ON

3-10: CONTINUITY WITH BLOWER S/W AT AUTO POSITION

12-10: CONTINUITY WITH BLOWER S/W AT LO, MED, HI POSITION

13-10: CONTINUITY WITH BLOWER S/W AT MED POSITION

4-10: CONTINUITY WITH BLOWER S/W AT HI POSITION

## (F) BLOWER SPEED CONTROL S/W

5, 4, 3, 6-8: EACH CLOSED WITH SERVO SHAFT MOVEMENT

## (J) AIR VENT MODE CONTROL SERVO MOTOR

3-13(8-12): CLOSED UNLESS HEATER CONTROL S/W A/T FOOT POSITION

## (K) WATER TEMP. S/W 20 °C (68 °F), 40 °C (104 °F)

1-3: CLOSED WITH COOLANT TEMP. ABOVE 40 °C (104 °F)

2-4: CLOSED WITH COOLANT TEMP. ABOVE 60 °C (140 °F)

## (Q) AIR MIX CONTROL SERVO MOTOR

5-6: RESISTANCE CHANGES RESPECTIVELY WITH SERVO SHAFT MOVEMENT

APPROX. 1.9 K $\Omega$  AT MAX. COOL POSITION

APPROX. 200  $\Omega$  AT MAX. HOT POSITION

## (W) DUAL PRESSURE S/W

1-2: OPEN WITH PRESSURE LESS THAN 2.1 KG/CM<sup>2</sup> (30 PSI, 206 KPA)  
OR ABOVE 27 KG/CM<sup>2</sup> (384 PSI, 2648 KPA)


## (C) HI PRESSURE S/W (CONDENSER FAN)














1-2: CLOSED ABOVE 18 KG/CM<sup>2</sup> (256 PSI, 1765 KPA)

OPEN BELOW 14 KG/CM<sup>2</sup> (199 PSI, 1373 KPA)


## (E) MAGNET CLUTCH

1-GROUND: APPROX. 3.7  $\Omega$







E3 BLUE




E4




K1




K2




K3




L1




M1 YELLOW




N1





# 34 GROUND POINTS







# 34 GROUND POINTS




**B1** YELLOW




**C1**




**D1**




**E1**




**E3** BLUE




**F1** BLUE




**H1** GREEN




**K1**




**M1** YELLOW




**N1**




**P1** BLUE




**Q2** BLACK




**R1**



**S1**




**T1**










# RELAY LOCATIONS



J/B No. 2]




# RELAY LOCATIONS




# RELAY LOCATIONS



[J/B No.3]




[R/B No. 4]



[J/B No. 7]




# ELECTRICAL WIRING ROUTING



- ① } A.B.S. Actuator
- ② } A.B.S. Speed Sensor (Front LH)
- ③ } A.B.S. Speed Sensor (Front RH)
- ④ } A.B.S. Speed Sensor (Rear)
- ⑤ } A/C Ambient Sensor
- ⑥ } A/C Condenser Fan Motor
- ⑦ } A/C Condenser Fan Relay
- ⑧ } A/C Dual Pressure S/W
- ⑨ } A/C Hi Pressure S/W (for Condenser Fan)
- ⑩ } A/C Magnet Clutch
- ⑪ } A/C Magnet Clutch Relay
- ⑫ } A/C Water Valve VSV
- ⑬ } A/T Indicator S/W (ECT)
- ⑭ } Air Flow Meter
- ⑮ } Alternator
- ⑯ } Back-up Light S/W (M/T) or Neutral Start S/W (A/T)
- ⑰ } Battery +
- ⑱ } Battery -
- ⑲ } Brake Fluid Lever S/W
- ⑳ } Check Connector
- ㉑ } Cold Start Injector
- ㉒ } Cruise Control Actuator
- ㉓ } Cruise Control Vacuum Pump [7M-GTE]

- ㉔ } Cruise Control Vacuum S/W [7G-GTE]
- ㉕ } Distributor [7M-GE] or Cam Position Sensor [7M-GTE]
- ㉖ } ECT Solenoid (ECT)
- ㉗ } EFI Resistor
- ㉘ } EFI Water Thermo Sensor
- ㉙ } Engine Hood Courtesy S/W (for Theft Deterrent System)
- ㉚ } FL 2.0L
- ㉛ } Fog Light LH
- ㉜ } Fog Light RH
- ㉝ } Front Side Marker Light LH
- ㉞ } Front Side Marker Light RH
- ㉟ } Front Turn Signal and Clearance Light LH
- ㊱ } Front Turn Signal and Clearance Light RH
- ㊲ } Fuel Pump Control Relay
- ㊳ } Fuel Pump Resistor
- ㊴ } Headlight Cleaner Motor
- ㊵ } Headlight Cleaner Relay
- ㊶ } Headlight LH
- ㊷ } Headlight RH
- ㊸ } Horn
- ㊹ } Ignition Coil [7M-GTE]
- ㊺ } Ignition Coil and Igniter [7M-GE]
- ㊻ } or Igniter [7M-GTE]
- ㊼ } Injector No. 1

- ㊽ } Injector
- ㊾ } Injector
- ㊿ } Injector
- 51 } Injector
- 52 } ISC Va
- 53 } Knock
- 54 } Knock
- 55 } Noise F
- 56 } Oil Pres
- 57 } Ox Sen
- 58 } Ox Sen
- 59 } Radiator
- 60 } Retractable
- 61 } Retractable
- 62 } Starter
- 63 } Starter
- 64 } Start In
- 65 } TEMS /
- 66 } TEMS /
- 67 } Theft D
- 68 } Throttle
- 69 } Turbo I
- 70 } VSV (f
- 71 } VSV (f
- 72 } VSV (f
- 73 } or VSV



Injector No. 2  
 Injector No. 3  
 Injector No. 4  
 Injector No. 5  
 Injector No. 6  
 Valve  
 Kick Sensor  
 Kick Sensor [7M-GTE]  
 Air Filter (for Ignition System)  
 Pressure Sender  
 Sensor [7M-GE]  
 Sensor [7M-GTE]  
 Motor Fluid Level S/W  
 Act Motor LH  
 Act Motor RH  
 Starter  
 Injector Time S/W  
 S Actuator Front LH  
 S Actuator Front RH  
 Deterrent Horn  
 Throttle Position sensor  
 Pressure Sensor  
 (for EGR) [7M-GE]  
 (for Fuel Pressure Up)  
 (for Intake Air Control) [7M-GE]  
 SV (for EGR) [7M-GTE]


- 78 Washer Motor (Front)
- 79 Washer Motor (Rear)
- 80 Water Temp. Sender
- 81 Wiper Motor
- 1A } Engine Room Main Wire and J/B No. 1
- 1B }
- 2A } Engine Room Main Wire and J/B No. 2
- 2B }
- 2D }
- 2E }
- 2F }
- A1 } Engine Room Main Wire and Cowl Wire
- A2 } (Left Kick Panel)
- A3 } Engine Room Main Wire and, Cowl Wire
- A4 } (Right Fender)
- C1 Engine Room Main Wire and Engine Wire
- (Engine Front Left)
- U1 Engine Wire and Engine No.4 Wire
- (Engine Rear Left)
- A Ground Right Fender
- B Ground Intake Manifold
- C Ground Left Fender

R/B


- J/B
- 1A
- 1B
- 1C
- 1D
- 1F
- 1G

- 1 } A.B.S. Computer
- 2 }
- 3 AC Sensor [7M-GTE]
- 4 A/C Air Mix Control
- 5 A/C Air Vent Mode C
- 6 A/C Amplifier
- 7 A/C Blower Speed Co
- 8 }
- 9 } A/C Check Connect
- 10 }
- 11 A/C In-car Sensor
- 12 A/C Recirc/Fresh Cor
- 13 }
- 14 } A/C Relay Box
- 15 A/C Short Pin
- 16 A/C Solar Sensor
- 17 A/C Thermistor
- 18 A/C Water Temp. S/W
- 19 Blower Motor
- 20 Blower Resistor
- 21 Cigarette Lighter
- 22 Clock
- 23 Clutch Start S/W
- 24 }
- 25 } Combination Meter
- 26 }
- 27 }
- 28 Combination Meter (C
- 29 }
- 30 } Combination S/W
- 31 Cruise Control Clutch
- 32 Cruise Control Compu
- 33 Cruise Control Main S







|    |                                                                            |    |                                                          |
|----|----------------------------------------------------------------------------|----|----------------------------------------------------------|
| 34 | Diode (for Fog Light System)                                               | 64 | TCCS ECU [7M-GTE]                                        |
| 35 | ECT ECU                                                                    | 65 | TEMS Steering Sensor                                     |
| 36 | ECT Pattern Select S/W                                                     | 66 | TEMS S/W                                                 |
| 37 | Fog Light Relay                                                            | 67 | Theft Deterrent Computer                                 |
| 38 | Fog Light S/W                                                              | 68 | Unlock Warning S/W                                       |
| 39 | Glove Box Light                                                            | 69 | Window Antenna Amplifier                                 |
| 40 | Glove Box Light S/W                                                        | 70 | Wiper Relay                                              |
| 41 | Hazard S/W                                                                 | 1A | } Engine Room Main Wire and J/B No.                      |
| 42 | Headlight Cleaner S/W                                                      | 1B |                                                          |
| 43 | } Heater Control Assembly                                                  | 1C |                                                          |
| 44 |                                                                            | 1F |                                                          |
| 45 | Ignition Key Cylinder Light                                                | 1G | } Cowl Wire and J/B No.1                                 |
| 46 | Ignition S/W                                                               | 1I |                                                          |
| 47 | Integration Relay No.2 (Retract Control Relay)                             | 1J |                                                          |
| 48 | Light Control Rheostat                                                     | 1K |                                                          |
| 49 | Noise Filter (for Rear Window Defogger)                                    | 1L | } Floor Wire and J/B No.1                                |
| 50 | O/D Main S/W and A/T Indicator Light                                       | 1M |                                                          |
| 51 | Parking Brake S/W                                                          | 1N |                                                          |
| 52 | Power Seat S/W (for Lumber and Side Support)                               | 1D |                                                          |
| 53 | R/B No.5 (Turn Signal Flasher, Power Main Relay, 30A Power CB, Horn Relay) | 3A | } Instrument Panel Wire and J/B No. 3 (Instrument Panel) |
| 54 | } Radio and Tape Player                                                    | 3B |                                                          |
| 55 |                                                                            | 3C |                                                          |
| 56 | Rear Window Defogger S/W                                                   | 7A | } Cowl Wire and J/B No.7 (Instrument Panel Left)         |
| 57 | Remote Control Mirror S/W                                                  | 7B |                                                          |
| 58 | Step Light                                                                 | 7C |                                                          |
| 59 | Stop Light S/W and Cruise Control Stop S/W                                 | 7D |                                                          |
| 60 | Super Monitor Computer                                                     | A1 | } Engine Room Main Wire and Cowl W (Left Kick Panel)     |
| 61 | } TCCS ECU                                                                 | A2 |                                                          |
| 62 |                                                                            | B1 | } Engine Wire and Cowl Wire (Behind Glove Box)           |
| 63 |                                                                            | B2 |                                                          |
|    |                                                                            | D1 | Cowl Wire and Ground Left Kick Pane (Left Kick Panel)    |




R/B No. 4



- E1** } Cowl Wire and Instrument Panel Wire
- E2** } (Left Kick Panel)
- E3** }
- E4** Cowl Wire and Instrument Panel Wire
- (Instrument Panel Left)
- E5** Cowl Wire and Instrument Panel Wire
- (Instrument Panel Left) [7M-GTE]
- F1** } Cowl Wire and Front Door LH Wire
- F2** } (Left Kick Panel)
- G1** Cowl Wire and Floor Wire
- (Left Kick Panel)
- H1** Instrument Wire and Floor Wire
- (Left Kick Panel)
- I1** Cowl Wire and Roof Wire
- (Left Kick Panel)
- K1** } Cowl Wire and Heater Wire
- K2** } (Instrument Panel Center)
- K3** }
- L1** Cowl Wire and A/C Wire
- (Behind Glove Box)
- M1** Engine Wire and Instrument Panel Wire
- (Behind Glove Box)
- N1** Cowl Wire and R/B No.4 Set Bolt
- (Right Kick Panel)
- O1** Cowl Wire and Floor No.2 Wire
- (Right Kick Panel)
- P1** } Cowl Wire and Front Door RH Wire
- P2** } (Right Kick Panel)
- D** Ground J/B No.1 Set Bolt
- E** Ground Left Kick Panel
- F** Ground Radio Left
- G** Ground R/B No.4 Set Bolt
- V** Ground Floor Center

- ① Auto Antenna Motor and Control Relay
- ② Back Door Courtesy S/W
- ③ Back Door Key Unlock S/W
- (for Theft Deterrent System)
- ④ Buckle S/W
- ⑤ Door Courtesy Light LH
- ⑥ Door Courtesy Light RH
- ⑦ Door Courtesy S/W LH
- ⑧ Door Courtesy S/W RH
- ⑨ Door Key Unlock S/W LH
- (for Theft Deterrent System) and Door
- Key Cylinder Light
- ⑩ Door Key Unlock S/W RH
- (for Theft Deterrent System)
- ⑪ Door Lock Control Relay
- ⑫ Door Lock Control S/W LH
- ⑬ Door Lock Control S/W RH
- ⑭ Door Lock S/W LH
- (for Theft Deterrent System) and Door
- Lock Key S/W LH (for Door Lock System)
- ⑮ Door Lock S/W RH
- (for Theft Deterrent System) and Door
- Lock Key S/W RH (for Door Lock System)
- ⑯ Door Lock Solenoid and S/W LH
- ⑰ Door Lock Solenoid and S/W RH
- ⑱ Fuel Pump
- ⑲ Fuel Sender
- ⑳ High Mount Stop Light
- ㉑ Interior Light
- ㉒ Licence Light LH
- ㉓ Licence Light RH
- ㉔ Light Failure Sensor

# ELECTRICAL WIRING ROUTING









- |    |                                                   |    |                                                                       |
|----|---------------------------------------------------|----|-----------------------------------------------------------------------|
| 25 | Luggage Compartment Light                         | 52 | Vanity Mirror Light RH                                                |
| 26 | Outside Handle S/W<br>(for Interior Light System) | 1D | Floor Wire and J/B No.1                                               |
| 27 | Power Seat Motor (for Front Vertical)             | D1 | Cowl Wire and Ground Left Kick Panel<br>(Left Kick Panel)             |
| 28 | Power Seat Motor (for Lumber Support)             | F1 | } Cowl Wire and Front Door LH Wire<br>(Left Kick Panel)               |
| 29 | Power Seat Motor (for Rear Vertical)              | F2 |                                                                       |
| 30 | Power Seat Motor (for Seat Slide)                 | G1 | Cowl Wire and Floor Wire<br>(Left Kick Panel)                         |
| 31 | Power Seat Motor (for Side Support)               | H1 | Instrument Panel Wire and Floor Wire<br>(Left Kick Panel)             |
| 32 | Power Seat S/W (for Vertical and Slide)           | I1 | Cowl Wire and Roof Wire                                               |
| 33 | Power Window Master S/W                           | N1 | Cowl Wire and R/B No.4 Set Bolt<br>(Right Kick Panel)                 |
| 34 | Power Window Motor LH                             | O1 | Cowl Wire and Floor No.2 Wire<br>(Right Kick Panel)                   |
| 35 | Power Window Motor RH                             | P1 | } Cowl Wire and Front Door RH Wire<br>(Right Kick Panel)              |
| 36 | Power Window S/W (Assistant)                      | P2 |                                                                       |
| 37 | Rear Combination and Side Marker<br>Light LH      | Q1 | Floor Wire and Seat Wire (Lumber and<br>Side Support) (Under LH Seat) |
| 38 | Rear Combination and Side Marker<br>Light RH      | Q2 | Floor Wire and Seat Wire (Vertical and<br>Slide) (Under LH Seat)      |
| 39 | Rear Window Defogger Choke Coil                   | R1 | Floor Wire and Floor No.2 Wire<br>(Floor Right)                       |
| 40 | Rear Wiper Motor and Relay                        | S1 | Floor Wire and Back Door No.1 Wire<br>(Left Center Pillar)            |
| 41 | Remote Control Mirror and Mirror<br>Heater LH     | T1 | Back Door No.1 Wire and Back Door<br>No. 2 Wire (Back Door Left)      |
| 42 | Remote Control Mirror and Mirror<br>Heater RH     | V  | Ground J/B No.1 Set Bolt                                              |
| 43 | Speaker Front LH                                  | E  | Ground Left Kick Panel                                                |
| 44 | Speaker Front RH                                  | F  | Ground Floor Left                                                     |
| 45 | Speaker Rear LH                                   | J  | Ground Floor Right                                                    |
| 46 | Speaker Rear RH                                   | K  | Ground Back Panel Center                                              |
| 47 | TEMS Actuator Rear LH                             |    |                                                                       |
| 48 | TEMS Actuator Rear RH                             |    |                                                                       |
| 49 | } TEMS Computer                                   |    |                                                                       |
| 50 |                                                   |    |                                                                       |
| 51 | Vanity Mirror Light LH                            |    |                                                                       |




# SYSTEM INDEX


TOYOTA SUPRA

1987 Model (Page 1 to Page 8)


| SYSTEMS                                                                                                                      | LOCATION | SYSTEMS                                                                                                                  | LOCATION |
|------------------------------------------------------------------------------------------------------------------------------|----------|--------------------------------------------------------------------------------------------------------------------------|----------|
| A.B.S.<br>(Anti-Lock Brake System)          | 8-1      | Power Source                          | 1-1, 8-3 |
| Air Conditioner,<br>Cooler and Heater       | 7-4      | Power Windows                         | 4-1      |
| Auto Antenna                                | 6-5      | Radio and Tape Player                  | 6-6      |
| Back-up Lights                              | 2-7      | Rear Window Defogger                   | 2-4      |
| Charging                                    | 1-8      | Rear Wiper and Washer                  | 3-2      |
| Cigarette Lighter                           | 6-4      | Remote Control<br>Mirrors with Heater  | 6-8      |
| Clock                                       | 6-4      | Starting                               | 1-2, 8-3 |
| Combination Meter                           | 2-2      | Stop Lights                            | 5-3      |
| Cruise Control                            | 5-1      | Super Monitor                        | 2-8      |
| Door Locks                                | 4-6      | Taillights and Illumination          | 5-4      |
| ECT (Electronic<br>Control Transmission)  | 2-6      | TCCS                                 | 1-5, 8-6 |
| Fog Lights                                | 5-8      | TEMS                                 | 3-7      |
| Front Wiper and Washer                    | 3-1      | Theft Deterrent<br>System            | 4-8      |
| Headlight Cleaner                         | 3-3      | Turn Signal and Hazard               | 3-4      |
| Headlights                                | 5-7      | Unlock and Seat<br>Belt Warning      | 6-1      |
| Horn                                      | 3-5      |                                                                                                                          |          |
| Interior Lights                           | 6-2      |                                                                                                                          |          |
| Power Seat                                | 4-3      |                                                                                                                          |          |




Power Source




Starting












Control Clutch S/W (5-2)






Charging




or Computer (2-8)  
(2-3)  
ector (1-5)

a  
b  
c  
d  
f

# 2 TOYOTA SUPRA (Cont'd)



A  
B  
C  
D  
E  
  
G  
H



a  
b  
c  
d  
e  
f


Ground points

a = Located on left fender

b = Located on engine block



Combination Meter




C = Located under left front pillar

d = Located under right front pillar


e = Located behind radio


f






## Rear Window Defogger







Back-up Lights



Super Monitor

7

8

A  
B  
C  
D  
E  
G  
H

A/T INDICATOR  
(COMB. METER)



BACK-UP LIGHT S/W  
(M/T)

R-B

LH



BACK-UP LIGHTS  
(REAR COMB. LIGHT)

RH



SUPER MONITOR COMPUTER

B-O From "ING" Fuse (1-7)

Y

L-Y From "RADIO No. 1" Fuse (6-6)

L-R From "CIG" Fuse (6-4)

G-Y To Cruise Control Computer (5-1)

G From "TAIL" Fuse (5-4)

P-G

Y-B

GR-G

W-L

R-G

B

BR

W-B

(1-6)  
(8-7)

(1-3)

(1-5)  
(8-1)

To TCCS ECU

To Speed Sensor (2-1)

From Igniter (1-7)(8-8)

W-B


1

BR


a  
b  
c  
d  
e  
f



# TOYOTA SUPRA (Cont'd)



Front Wiper and Washer




Rear


A  
B  
C  
D  
E  
G  
H

1

2




Wiper and Washer



Headlight Cleaner


3



t front pillar

f = Located on back panel





Turn Signal and Hazard



Horn

4

5

H

7.5A  
TURN

1

G-R

W

HAZARD S/W

|     | B1 | F | B2 | TL | TB | TR |
|-----|----|---|----|----|----|----|
| OFF |    |   |    |    |    |    |
| ON  |    |   |    |    |    |    |

G-R

G-B

G-O

G-Y

LH  
RH

TURN SIGNAL S/W  
(COMB. S/W)

INDICATOR LH  
(COMB. METER)

W-B

FRONT LH

W-B

REAR LH  
(REAR COMB. LIGHT)

W-B

INDICATOR RH  
(COMB. METER)

G-Y

FRONT RH

G-Y

REAR RH  
(REAR COMB. LIGHT)

G-Y

TURN SIGNAL LIGHTS

W-B

W-B

3

1

E

15A  
HAZ-HC

2

W

W

1

W

W

W

W

W

W

W

W

W

W

W

W

W


W

W

W

To Theft Deterrent Horn (4-8)

W



L-R

L-B

7


L-R

L-R

To Theft Deterrent Computer (4-8)

HORN S/W  
(COMB. S/W)







8

- *A*
- *B*
- *C*
- *D*
- *E*
- *G*

To Speed Sensor  
(2-1)

a.

Diagram of the TCCS ECU wiring harness:

- R-W, R, B: From TCCS ECU (1-6) (8-7)
- G-W: From Stop Light S/W (5-3)

TEMS COMPUTER

GR-B

R-6

8-8

α

W-B

INDICATOR  
(METER)

TEMS ACTUATOR

FRONT LH

FRONT RH

REAR LH

REAR RH

W-B

W-B

W-B


1

1


- *a*
- *c*
- *d*
- *f*



# 4 TOYOTA SUPRA (Cont'd)



## Power Windows



Ground points

*a* = Located on left fender

*C* = Located under left front pillar


*d* = Located under right



Power Seat


2

3




4

5








# Door Locks


6

## DOOR LOCK CONTROL RELAY





Theft Deterrent System








## Cruise Control

1 2

A  
B  
D  
E  
G






# Stop Lights

3

A



20A  
STOP

W 1  
W

To A.B.S. Computer (8-2)

STOP LIGHT S/W

G-W

G-W

To ECT ECU (2-5)  
To TEMS Computer (3-8)

From A.B.S. Computer (8-2)

LIGHT FAILURE SENSOR

From "GAUGE" Fuse (2-3)

From Rear Lights Failure  
Warning Light (2-2)

LICENCE PLATE RH

LICENCE PLATE LH

REAR SIDE MARKER RH  
(REAR COMB. LIGHT)

REAR SIDE MARKER LH  
(REAR COMB. LIGHT)

TAIL RH  
(REAR COMB. LIGHT)

TAIL LH  
(REAR COMB. LIGHT)


To Super Monitor

FRC



FRC

TCCS ECU  
(8-7)


CRUISE CONTROL  
CLUTCH S/W (M/T)



HIGHT MOUNTED STOP LIGHT










# Taillights and Illumination

4

5









# 6 TOYOTA SUPRA (Cont'd)




## Unlock and Seat Belt Warning

A

B

E

G




c


d

Ground points

C = Located under left front pillar



## Interior Lights



d = Located under right front pillar




Clock

4



Cigarette Lighter


5







Auto Antenna




Radio and Tape Player

6

From "ECU-IG" Fuse (3-6)

AUTO ANTENNA CONTROL  
RELAY AND MOTOR





WINDOW ANTENNA  
AMPLIFIER



B-R

To Theft Deterrent Computer (4-8)  
To Clock (Digital) (6-4)  
To ECT ECU (2-5)  
To Super Monitor Computer  
(2-8)  
To Heater Control Assembly  
(7-7)






## Remote Control Mirrors with Heater

7

8

B

From Defogger Relay  
(2-4)



1

GR

### REMOTE CONTROL MIRROR S/W

|    |       | B | E | H1 | V1 | C | V2 | H2 |
|----|-------|---|---|----|----|---|----|----|
| RH | UP    | ○ | ○ |    |    | ○ | ○  |    |
|    | DOWN  | ○ | ○ |    |    | ○ |    |    |
|    | LEFT  | ○ | ○ |    |    | ○ |    | ○  |
|    | RIGHT | ○ | ○ |    |    | ○ |    | ○  |
| LH | UP    | ○ | ○ | ○  | ○  |   |    |    |
|    | DOWN  | ○ | ○ | ○  | ○  |   |    |    |
|    | LEFT  | ○ | ○ | ○  | ○  |   |    |    |
|    | RIGHT | ○ | ○ | ○  | ○  |   |    |    |

W-B


BR-B

BR-Y


LG-R

LG-B

BR-R



LH



RH


MIRROR MOTORS

MIRROR HEATER LH

W-B V-R


MIRROR HEATER RH

W-B V-R



c  
d

# TOYOTA SUPRA (Cont'd)




Ground points

a = Located on left fender

c = Located under left front pillar

d = Located under right front pillar









# Air Conditioner, Cooler and Heater


4

5










8 TOYOTA SUPRA (Cont'd)



A.B.S. (Anti-Lock Brake System)




Ground points      a = Located on left fender      b = Located on engine block      c = Located un



Power Source

2

3





Starting

4

5

